

SPRAY • WIPE • RINSE

aero.

POWER SCRUB

DISH SPRAY



TYPICAL PROPERTIES

- pH: 11.0
- Solids: 13%
- Appearance: Clear blue liquid
- Fragrance: Fresh

SAFETY CAUTIONS

Keep out of reach of children. Read label and SDS before use. Causes serious eye damage and skin irritation. Combustible liquid.

Refer to SDS for additional safety information.



**SPRAY
WIPE
RINSE**

CLINGING FOAM FOR ALL DISHES:

- Plates
- Greasy Pots
- Baking Racks
- Glasses
- Pans
- Fryer Baskets
- Silverware
- Cutting Boards

DIRECTIONS

Spray directly on dishes, wipe, and rinse.

For heavy soil, allow foam to penetrate for a few minutes, then wipe and rinse.