

AERO® Live Bacteria / Enzymes products contain a synergistic blend of engineered bacterial strains for effective removal of various organic soils. Fortified with free enzymes and detergents.

# aero



## SURVIVORS®

BIOLOGICAL WASTE DEGRADER

### Grease Trap & Drain Line Maintainer

- Bleach Resistant
- Heat Resistant
- Disinfectant Resistant
- Alkali Resistant
- Non-Polluting
- Chlorine Resistant

#### GET READY FOR A NEW LEVEL OF PERFORMANCE!

The future belongs to **SURVIVORS®**. A technological breakthrough that Mother Nature tried to keep a secret. You may have used waste degraders before, but **SURVIVORS®** is different—a new, exclusive formulation backed by a team of experienced scientists and researchers. This genetically programmed group of organisms begins instantaneous degradation of food by-products (oil, grease, fats, etc...) that contaminate and clog your grease traps and drain lines.

This **BIO-ENZYMATIC** powerhouse is resistant to....

- BLEACH • DISINFECTANT • ALKALIES • CHLORINE • HEAT (up to 180° F)
- ....which have rendered many ordinary waste degraders ineffective.

**SURVIVORS®** is designed for use in restaurants and food service establishments where odor-causing grease traps are present. In addition, **SURVIVORS®**, with an excess of 100 billion microorganisms per gallon, effectively degrades solid waste that accumulates in lift stations, septic tanks, porta-toilets, and drain pipes.

BOD (Biological Oxygen Demand) levels are a major concern of your local water treatment facility. This is a costly problem that could be passed on to you in the form of waste water surcharges.

#### DIRECTIONS

**GREASE TRAPS:** Use 8 to 20 oz. of product daily depending on the size of the grease trap, type of cooking, cleaning procedures and volume. Used properly, this product will drastically reduce costly pumping charges and BOD waste water surcharges.

**DRAIN PIPES: For Slow Drains:** Pour 4 to 8 ounces of product in drain. Let stand overnight. Repeat in two or three days. If drain has not improved, check for obstruction. **To Prevent Slow Drains:** Pour 4 to 6 ounces down each drain, shower, lavatory, kitchen sink, or commode once each month. Double this amount for septic tanks.

**LIFT STATIONS:** Treat directly as the wells fill and add at least 3-5 gallons per million gallons of flow through capacity. Repeat with one gallon treatment per week as a preventative maintenance program to maintain an odor free system.

**SEPTIC TANKS:** Add 1 quart for initial treatment. Thereafter use 8 ounces per week by flushing down commode.

**PORTABLE TOILETS:** Add 1 gallon directly to toilet and cover solids with water to aid digestion. Repeat procedure every time the toilet is pumped.

Manufactured exclusively for:

**Aero Chemical Co.,** division of ABC Compounding Co., Inc.  
P. O. Box 16247, Atlanta, GA 30321 • 770-968-9222  
800-795-9222 • www.abccompounding.com

#### HIGHLIGHTS

- Rapid bacteria replications
- Heat resistant
- Bleach resistant
- Alkali resistant
- Disinfectant resistant
- Reduces suspended solids
- Reduces sludge volume
- Reduces BOD
- Non-pathogenic

#### TYPICAL PROPERTIES

- pH: 8.7
- Specific Gravity: 1.0
- Appearance: White
- Fragrance: Cherry
- Bacteria Count: 100 billion/gallon

#### SAFETY CAUTIONS

Keep out of reach of children. Read label and SDS before use. Flammable liquid and vapor.

Refer to SDS for additional safety information.



Nonfood Compounds  
Program Listed C1  
Registration # 134615